AX-48 PRO ACCESSORIES

AX-48 Pro Mic Boom • Microphone Boom and Adapter (AX-48 ProMic, #17366)

AX-48 Pro Third Tier

- Super Clamp (CMP-485, #11853)
- 13" Tribar Pair Arms (TBR-130, #16535)
- 18" Tribar Pair Arms (TBR-180, #16534)



AX-48 Pro Mic Tote Bag

. Heavy-duty Tote Bag (AX-48 ProBag, #17367)



Visit ultimatesupport.com to read full warranty details & to register for warranty

ULTIMATE SUPPORT


LIMITED LIFETIME WARRANTY

Ultimate Support products are constructed of the finest materials and designed and tested to stand up to the demanding lifestyle of the touring muscian, gigging DJ, and working sound engineer. In the unlikely event that a product should fail due to manufacturing defect, Ultimate Support is pleased to repair or replace that product.

Please see www.ultimatesupport.com for more information.

This warranty applies to the original purchaser only and does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.

800.525.5628 . www.ultimatesupport.com Copyright 2015, Ultimate Support Systems . All Rights Reserved





SETUP

PARTS INCLUDED: A. Ulti-Boom Pro (mic boom) B. AX-48TA (adapter) C. (2) Bolts D. Allen Wrench A. C.



STEP 1: Locate groves on APEX® AX-48 Pro top plate.



STEP 3: Remove accessory cap.



STEP 5: Using provided allen wrench, screw bolts into place. Do not over tighten.



STEP 2: Using a flat tip screw driver, remove accessory cap by wedging head into groves and gently applying pressure.



STEP 4: Replace accessory cap with AX-48TA adapter.



STEP 6: Attach Ulti-Boom Pro to the top of the accessory cap and adjust as desired.